

Production

Grass Valley K-Frame 3G Switcher
- Kayenne 4 Stripe 35 Button Panel
-7 M/E, 96 Inputs, 48 Outputs
-Image Store w/movies

Camera Equipment - Triax Truck

Grass Valley LDX 86 Worldcam Triax Cameras

Wired for 16 CCU's

Other Camera and Lens configurations available

A/V Support

(6) HMD26 Annc Headsets
(6) Studio Tech Annc Boxes
(6) MD46 Stick Mics
(6) MKH416 Shotgun Mics
(6) MKH8070 Long Shotgun Mics
(4) MKH418 Stereo Shotgun Mics
(6) 15" SDI Monitors
(6) 21" SDI Monitors
(2) LED Light Kits

Audio Facilities

Calrec Artemis Beam Surround Sound Console
-64 Fader Digital Audio Console
-96x96 Analog
-64x64 AES Channels
-384x384 MADI Channels
-64x64 DANTE Channels
-64x64 Waves Broadcast Suite Software

Communications

256x256 RTS Adam Matrix Intercom Including
-64 OMNEO CH's,
-16 RVON CH
-64 MADI Channels
-12 Powered PL Channels
-12 Powered IFB Channels

Cable Inventory

Contact Operations for Specific List

Routing & Terminal

Evertz EQX 3G Video Router (316x322)

Includes:

-112x48 Embedding/Dis-embedding
-18 Frame Sync with De-embedding
-16 Fiber Inputs and Outputs

Evertz EMR Audio Router

-1024 x 1024 MADI
304x23 Multiview Capacity
(40) Framesyncs


- 40 EVS Neuron HDR Frame Syncs w/
Custom LUT & CC
(4) TX Processors w/ U/D/C


Replay

Up to 3 12ch EVS VIA and 1 Spotbox

Power Requirements

Three Phase, 208 Volts, 200amp
-200' Feeder Cable





MONITOR 1A				MONITOR 2A				MONITOR 3A				MONITOR 4A					
										12:00PM						12:00PM	
1	2	3	4	1	2	3	4	1	2		3	4	1	2	3	4	
				12:00PM													
				PROGRAM				5	6	7	8	9	5	6	7	8	9
5	6	7	8			5	6	PROGRAM		PREVIEW							
9	10	11	12	7	8	9	10	11		13		14	15	16			

MONITOR 5A				MONITOR 6A				MONITOR 7A				MONITOR 8A				
												1	2	3	4	5
1	2	3	4	1	2	3	4	1	2	3	4					
												6	7	8	9	10
5	6	7	8	5	6	7	8	5	6	7	8					
												11	12	13	14	15
9	10	11	12	9	10	11	12	9	10	11	12	16	12:00PM			

MONITOR 9A (P2-CG)

		5
1	2	6
		7
3	4	8

MONITOR 9B (P3-BUG)

		13
9	10	14
		15
11	12	16

SWITCHER INPUTS

IN	Default	Show Name	Operator	Source	IN	Default	Show Name	Operator	Source	IN	Default	Show Name	Operator	Source	IN	Default	Show Name	Operator	Source
1	CAM 1				25	VTR A				49	EVS 8A				73	RTR FEED			
2	CAM 2				26	VTR B				50	EVS 8B				74	RTR FEED			
3	CAM 3				27	VTR C				51	CS-1				75	RTR FEED			
4	CAM 4				28	VTR D				52	CS-2				76	RTR FEED			
5	CAM 5				29	VTR E				53	EVS 5A	SPOT A			77	RTR FEED			
6	CAM 6				30	VTR F				54	EVS 5B	SPOT B			78	RTR FEED			
7	CAM 7				31	RTR FEED				55	EVS 5C	SPOT C			79	RTR FEED			
8	CAM 8				32	RTR FEED				56	EVS 5D	SPOT D			80	RTR FEED			
9	CAM 9				33	RTR FEED				57	FS 1				81	RTR FEED			
10	CAM 10				34	RTR FEED				58	FS 2				82	CG 1A F			
11	CAM 11				35	EVS 1A				59	FS 3				83	CG 1A K			
12	CAM 12				36	EVS 1B				60	FS 4				84	CG 1B F			
13	CAM 13				37	EVS 2A				61	FS 5				85	CG 1B K			
14	CAM 14				38	EVS 2B				62	FS 6				86	CG 2A F			
15	CAM 15				39	EVS 3A				63	FS 7				87	CG 2A K			
16	CAM 16				40	EVS 3B				64	FS 8				88	CG 2B F			
17	CAM 17				41	EVS 4A				65	FS 9				89	CG 2B K			
18	CAM 18				42	EVS 4B				66	FS 10				90	BUG 1 F			
19	CAM 19				43	RTR FEED				67	FS 11				91	BUG 1 K			
20	CAM 20				44	RTR FEED				68	FS 12				92	TELE F			
21	CAM 21				45	EVS 6A				69	FS 13				93	TELE K			
22	CAM 22				46	EVS 6B				70	FS 14				94	RTR FEED			
23	CAM 23				47	EVS 7A				71	FS 15				95	BLACK			
24	CAM 24				48	EVS 7B				72	FS 16				96	BARS	BARS		

SWITCHER GOP's

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	

MONITOR 10A

MONITOR 11A

MONITOR 12A

MONITOR 13A

1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
5	6	7	8	5	6	7	8	5	6	7	8	5	6	7	8
9	10	11	12	9	10	11	12	9	10	11	12	9	10	11	12

DDR:____
(KVM8)

DDR:____
(KVM9)

DDR:____
(KVM10)

DDR:____
(KVM13)

MONITOR 15A

MONITOR 16A

1	2	3	4	1	2	3	4
5	6	7	8	5	6	7	8
9	10	11	12	9	10	11	12

DDR:____
(KVM LT)

DDR:____
(KVM CTR)

DDR:____
(KVM RT)